# NUCRAFT

Installation Instructions ID:

Ascari Conference with Island Bases

## Before Beginning Installation

- Read through the entire instruction thoroughly
- A minimum of 2 persons is required for this assembly
- If damage is found, STOP. Document damage and packaging and report to dealer.

#### **Required Tools**








 $\hspace{0.1cm}$ %" / 6mm Allen Wrench or Hex Bit




- 3/8" Socket Wrench
- **Basic Tool Kit**







# Steps



#### Assembling Base


- Island Bases can come pre-assembled in various stages.
- Match beams and based to their labeled locations.
- Ensure beams are level and secure all beams by tightening bolts of clamp bars. Loosen and tighten bolts with ¼" Allen wrench.
- Beams will have silver mark to indicate end base location.
- Ensure base is level length and width wise.
  - Adjust glides and beams if necessary.









Beams slide on bars




### Lower Sub Top

- Note: Sometimes the Lower Sub Top ships attached to the Upper Sub Top. Continue to next step if this is the case for your table.
- Place lower sub top on beams and center between frame ends.
- If necessary, connect tops with dog bone fasteners.
- Attach sub top to base using 1" screw marked with a yellow sticker
- Continue to ensure base remains level throughout assembly process.









#### Upper Sub Top

- Place Upper Sub Top (connect with dog bones if necessary)
- Use the Green Screw to attach the Lower Sub Top to the Upper Sub Top.
- If Glass or Stone Top is specified, secure Upper Sup Top with Yellow Screws thru tabs welded onto the Steel Sub Frame.










#### **Under Mounted Power Options**

- Power Drawers and Low Profile Perimeter Power Units are installed from the bottom of the table.
- Under mounted power options are pre-installed at the factory and only removed if they fall on a seam of the top.
- The power option will only require a wire management tray when it is located on the lower sub top
- If Bluetooth lighting has been specified, consult the manual provided with the remote.
- Please consult the Modular Power Installation Instructions on Nucraft's Website for assistance with Jumpers, Duplex and Infeeds.








#### Metal Reveal (If Specified)

 If a table requires a metal reveal; attach it to the corresponding location that is marked on the upper sub top as shown on the right.


- Place 1/8" White Melamine Spacer panels after reveals are installed.
  Panels will be marked for location and have dowel hole locators
- If there are no reveals required, then proceed to the next steps








#### Veneer Top



### Glass Tops

- Supplied bumpers should be applied to the sub top at the edges and corners of where each glass panel will rest.
- Spacing between bumpers should be no more than 2 feet apart along the edges and across the middle of each glass top segment
- Set glass so edges run evenly with sub tops and reveals.
- There may be slight variance from glass top to sub top as there are tolerances on glass.





#### Stone Tops

- Installers specifically trained in the installation of these materials must be utilized to ensure a quality installation.
- Nucraft shall not be liable for any damages incurred during the handling and/or installation of natural stone or solid surface materials on its products

